


# COOKTOP PARTS

For Models: RF362LXTQ0, RF362LXTT0, RF362LXTB0, RF362LXTS0, RF362LXTY0

(Designer White) (Designer Biscuit) (Black) (Black Stainless) (Universal Silver)



30" ELECTRIC CERAN  
FREESTANDING RANGE  
SELF CLEAN OVEN



Illus. No.	Part No.	DESCRIPTION
1	9762996	Literature Instructions, Installation Template, Anti-Tip
	9757142	English/Spanish
	9757143	English/French
	9763001	Owners Manual
	W10117560	Tech Sheet
	9762761	Safer Cooking Tips


Illus. No.	Part No.	DESCRIPTION
2	W10035930	Spring, Locator
3	3196170	Screw
4	9763330	White
	9763331	Biscuit
	9763332	Black

Illus. No.	Part No.	DESCRIPTION
5	8523047	Element, Surface 2400/1000W LF,RF
	8273994	1200W LR,RR
6	8272791	Bracket, Element
7	3196169	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PANEL PARTS

For Models: RF362LXTQ0, RF362LXTT0, RF362LXTB0, RF362LXTS0, RF362LXTY0  
(Designer White) (Designer Biscuit) (Black) (Black Stainless) (Universal Silver)



Illus. No.	Part No.	DESCRIPTION
1	W10009080	Black Left
	W10009090	Black Right
	W10009040	White Left
	W10009050	White Right
	W10009060	Biscuit Left
	W10009070	Biscuit Right
2	9757609	Nameplate
3		Panel, Control
	W10117577	Black
	W10117875	Biscuit
	W10117576	White
	W10117578	Stainless


Illus. No.	Part No.	DESCRIPTION
4	9758060	Switch, Infinite
	3148951	Front (LF,RF)
	8523265	Rear (RR,LR)
5	8523265	Light, Ind. (2)
6	3196068	Lens, Light (2)
7		Knob, Infinite (4)
	9761964	Black
	9761962	White
	9761963	Biscuit
8	8523280	Shield, Heat
9	3196166	Screw

Illus. No.	Part No.	DESCRIPTION
10	8272473	Cover, Upper
11	9762095	Brkt-Mntg, Console
12		Control, Range
	W10114377	Black
	W10114376	White
	W10114378	Biscuit
13	3196178	Screw
14	9762078	Brkt-Mntg, EOC
15	3400882	Screw
16	8273564	Clip

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CHASSIS PARTS

For Models: RF362LXTQ0, RF362LXTT0, RF362LXTB0, RF362LXTS0, RF362LXTY0  
(Designer White) (Designer Biscuit) (Black) (Black Stainless) (Universal Silver)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CHASSIS PARTS

For Models: RF362LXTQ0, RF362LXTT0, RF362LXTB0, RF362LXTS0, RF362LXTY0  
(Designer White) (Designer Biscuit) (Black) (Black Stainless) (Universal Silver)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	9760407	Brkt-Mntg,Dr Hnge	16	8054068	Tray, Insulation	36	9758283	Cover, Box
2	8273905	Support, Corner LR	17	3196576	Clip, Panel (6)	38	3196165	Screw
3		Panel, Side (2)	18	9760314	Rail, Base (2)	39	3196168	Screw
	8053830	White-Textured	19	W10058460	Foot, Rear (2)	40	3196178	Screw
	8272519	Biscuit-Textured	20	9761490	Insulation	41	3196174	Screw
	8053832	Black-Textured	21	9761512	Clip- Mounting	42	3196179	Screw
4	9761013	Latch, Door	22	9758238	Retainer, Side (2)	44	W10031780	Screw
5	W10078380	Rod, Latch	23	8273902	Sensor, Oven	46	3400016	Screw
6	W10107820	Latch Asy, Rear	24	3195736	Support, Front (2)	47	3196566	Screw
7	W10010350	Seal, Oven Flange	25	3195987	Support, Corner RR	48	9757262	Switch - Door
8	9757340	Element, Broil	26	3196548	Fuse, Thermal	49	9757239	Rod - Door Switch
9	9758541	Element, Bake	27	3196172	Screw			Rear Mount
10	8522416	Seal, Oven Door	28	3186116	Support, Oven (2)	50	9761301	Screen - Catalyst
11	9758701	Spacer, Door	29	3186034	Bracket, Service			
12	3196560	Screw	30	9761958	Block, Terminal			
13	9759785	Glide, Drawer (2)	31	8274034	Back, Main			
14	3196037	Foot, Front (2)	32	112432	Nut (3)			
15		Frame, Front (Not Serviced)	33	9761300	Vent Tube Asm			
			34	3196701	Light Socket Assy			
			35	311255	Bulb, Oven Light			


## INSULATION

8272616 Insulation, Wrap  
8272612 Insulation, Back  
8272613 Insulation, Vent

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DRAWER & BROILER PARTS

For Models: RF362LXTQ0, RF362LXTT0, RF362LXTB0, RF362LXTS0, RF362LXTY0  
(Designer White) (Designer Biscuit) (Black) (Black Stainless) (Universal Silver)



Illus. No.	Part No.	DESCRIPTION
1	3195710	Rack, Oven (2)
2	9761030	Drawer, Storage
3	9758200	Bracket, Drawer(2)
4		Rivet, Push (2)
	3196814	White
	3196813	Black
	3196815	Almond


Illus. No.	Part No.	DESCRIPTION
5		Drawer Front
	8053339	White
	8272501	Biscuit
	8053341	Black
6	8053334	Glide, Drawer (2)
7	3196168	Screw
8	9755798	Panel (Stainless Model)

Illus. No.	Part No.	DESCRIPTION
9		Handle
	9757219	(Stainless Model)
	9762251	Univ. Slvr. Mdl.
10	W10031790	Screw (Stainless Model)
11	9781235	Clip

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR PARTS

For Models: RF362LXTQ0, RF362LXTT0, RF362LXTB0, RF362LXTS0, RF362LXTY0  
(Designer White) (Designer Biscuit) (Black) (Black Stainless) (Universal Silver)



**Illus. Part**  
**No. No. DESCRIPTION**

1		Trim, Top
	9762391	Black
	9761976	Biscuit
	9761975	White
	9762394	Black/Stainless
	Model	
	W10067560	Univ. Slvr. Model
2	3196164	Screw
3		Handle, Door
	9761983	Black
	9761984	Biscuit
	9761982	White
	9761985	S.Steel
4	9761344	Liner, Door
5	8522414	Seal, Window
6	9758162	Glass, Inner (2)
7	3186289	Frame, Glass
8	8272618	Insulation, Door

**Illus. Part**  
**No. No. DESCRIPTION**

9	9761357	Retainer, Insln
10	9761493	Hinge, Door (2)
11		Glass, Outer Door
	W10075990	Black
	W10075980	White
	W10076000	Biscuit
	9756417	Black/Stainless
12		Trim, Side
	8523171	Black Left
	8523165	Black Right
	8523173	Biscuit Left
	8523167	Biscuit Right
	8523172	White Left
	8523166	White Right
	W10113925	Gray Right
	W10113926	Gray Left

**Illus. Part**  
**No. No. DESCRIPTION**

13	3196160	Screw
14		Trim, Bottom
	8523177	Black
	8523178	Biscuit
	8523175	White
	8523180	Black/Stainless
	Model	
	W10067550	Univ. Slvr. Model
15	W10031790	Screw
16	W10113759	Strap, Door
17	3196025	Clip, Door Glass
18	3196794	Bracket, Window(2)
19	3196165	Screw
21	9761517	Clip, Dr Mntg (2)
22	W10031780	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS

For Models: RF362LXTQ0, RF362LXTT0, RF362LXTB0, RF362LXTS0, RF362LXTY0  
(Designer White) (Designer Biscuit) (Black) (Black Stainless) (Universal Silver)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

Parts Not Illustrated and  
Optional Parts (Not Included)

## SPLICING WIRES--25FT.

### LENGTH

242828	Wire, Black
	12 Ga. 150° c
242821	Wire, Blue
	14 Ga. 150°c
242822	Wire, Brown
	14 Ga. 150°c
242830	Wire, Brown
	14 Ga. 200°c
242823	Wire, Green
	14 Ga. 150°c
242824	Wire, Orange
	14 Ga. 150°c
242825	Wire, Red
	14 Ga. 150°c
242831	Wire, Red
	14 Ga. 200°c
242827	Wire, Yellow
	14 Ga. 150°c

## REFINISHING MATERIAL

799832	Kit, Porcelain Repair (White)
242756	Touch-Up Self-Clean(1/2 Pt)
261582	Grease

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

## INSULATION

261514	Insulation, Fiberglass (1-1/2" x 24" x 120")
240132	Insulation, Fiberglass (2-1/2" x 22" x 120")

## PAINT, TOUCH-UP (1/2oz.)

72017	White
72107	Almond
511873	White Porcelain (2 Oz.)

## PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
350956	Almond
285006	Superior Black
206922	Primer (White)

## PAINT, BULK (1 qt.)

799344	White (Uncut)
978883	Almond (Uncut)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

## ACCESSORY PARTS

241430	Foil, Aluminum Oven (18" x 25')
3191048	Cleaner, Glass

## ANTI-TIP KIT

W10017440	Anti-Tip Kit
-----------	--------------

## WIRING HARNESS PARTS

W10115055	Harness, Wire (Cooktop Left)
W10115056	Harness, Wire (Cooktop Right)
9762428	Harness, Wire (Sensor)
W10121263	Harness, Wire (Main)
8523279	Wire, Ground
8524132	Shield, Wiring
313660	Clip, Ground Wire
3196173	Screw
3196154	Screw, Ground

## Miscellaneous

814381	Pin Kit-Dr Removal
--------	--------------------

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST